


INSTRUCTIONS MANUAL

PLEASE READ THE MANUAL BEFORE FIRST USE AND IMPERATIVELY OPERATE THE WATCH AS INDICATED IN IT. KEEP THIS MANUAL SAFE FOR FUTURE REFERENCE!

This watch is a self-winding mechanical watch that does not require a battery, and winds itself throughout the day as its wearer performs certain everyday movements while the watch is on his wrist.

PRODUCT DESCRIPTION



- 1. Mini power reserve dial
- 2. Mini calendar dial
- 3. Mini second-hand dial
- 4. Hour hand
- 5. Minute hand

- A. Push button to set the date
- B. Time setting and winding crown

Note: The tachymeter scale around the dial is also decorative.



TIME AND DATE SETTING

	<ul style="list-style-type: none"> • Position 0: Normal running position • Position 1: <u>TIME SETTING</u> <ul style="list-style-type: none"> ✓ Gently pull the crown to position 1 and turn it clockwise to set the time. ✓ Push the crown to position 0 to confirm and complete the setting.
	<p>Bouton A: <u>DATE SETTING</u></p> <ul style="list-style-type: none"> • Press button "A" successively to quickly set the date <p> In order to allow the date to be changed the next day, the date must not be set between 10 p.m. and 2 a.m.</p>

WATCH FEATURES

- Power reserve of the watch when fully wound and without being worn (See procedure for winding procedure in "Operating instructions" section below, paragraph 1): about 50 hours
- Water resistant: 2 ATM

OPERATING INSTRUCTIONS

1. For the first time use, in order to start your watch, hand wind it manually by turning the crown clockwise in normal crown position. Continue to turn it until the red hand on the power reserve dial points to "Full". This inscription indicates that the energy stored in the spring is full

Note: The power reserve dial tells you the amount of energy present or remaining in the watch. This lets you know when it's time to wind it to ensure continued operation.

IMPORTANT NOTES:

- The watchband must be fitted correctly to the wearer's wrist. If the watchband is too loose or too tight, the watch may lose some of its autonomy and may not wind itself correctly. For optimal winding, wear your watch daily.
- If you don't wear the watch for a long time, the watch may stop, and you will then need to wind it manually to provide it with the necessary power reserve. Please repeat the steps in paragraph 1 above. Be sure to also follow the notes in this frame.
- **DO NOT** try to wind the watch any further after feeling this resistance as any further strain could cause the main spring to break.
- **DO NOT** turn the crown counter clockwise as this might damage the mechanism of the watch.

WARNINGS

- To maintain the aesthetic appearance of your watch, avoid contact with perfumes, nail polish, varnish, cosmetics, cleaning products, adhesives, and paint, as they can cause discoloration, deterioration and damage.
- To prevent any risk from perspiration, dust and humidity, regularly wipe your watch with a soft, dry cloth.
- To ensure the longevity of your watch, do not attempt to open the watch casing.

Imported by EML – trading name Prodis 1, rue de Rome 93110 Rosny-sous-Bois-France/
Made in P.R.C.

Marketed by EUROTUPS VERSAND GMBH, Elisabeth-Selbert-Str.3, D-40764
LANGENFELD

